




instructions 1/3







2.



Press red lever to fold out Mop Frame



While Mop Frame is folded insert Mop Frame ends into the pockets of the Premium Microfiber Mop





Press in the middle of the Mop Frame until you hear a click securing the Premium Microfiber Mop in place



MOPPING KIT

instructions 2/3





Connect the red tip of the Flex-Ex Handle with the Mop Frame



MOPPING KIT

instructions 3/3





