




# FAYINA

# FLEX-EX HANDLE

instructions

1.

Squeeze red locking ring to release flexible arm



Built-in loop for easy storage. Hang it in compact places with our wall mounted storage hanger

\*hanger sold separately




Telescopic Handle with a maximum length of **65 IN**




Featuring an extra 20 inches of flexible arm that is perfect for cleaning underneath furniture

2.



Connect the red tip of the Flex-Ex Handle with the Mop Frame

\*mop & mop frame sold separately



Push down handle as you are mopping to reach underneath furniture